

embOS

Real Time Operating System

CPU & Compiler specifics for
ARM core with
ARM RealView Developer Kit 2.1
for STMicroelectronics

Document Rev. 1



A product of Segger Microcontroller Systeme GmbH

www.segger.com

Contents

Contents	3
1. About this document	4
1.1. How to use this manual.....	4
2. Using embOS with ARM RealView Developer Kit	5
2.1. Installation.....	5
2.2. First steps	6
2.3. Stepping through the sample application Main.c using the integrated debugger. 9	
3. Build your own application.....	15
3.1. Required files for an embOS application	15
3.2. Change library mode.....	15
4. ARM specifics.....	17
4.1. CPU modes	17
4.2. Available libraries.....	17
5. Stacks	18
5.1. Task stack for ARM 7 and ARM 9.....	18
5.2. System stack for ARM 7 and ARM 9	18
5.3. Interrupt stack for ARM 7 and ARM 9	18
5.4. Stack specifics of the ARM family.....	18
6. Heap.....	19
6.1. Heap management	19
7. Interrupts	20
7.1. What happens when an interrupt occurs?	20
7.2. Defining interrupt handlers in "C"	20
7.3. Interrupt handling with vectored interrupt controller	21
7.4. Interrupt-stack switching	26
7.5. Fast Interrupt FIQ	26
8. STOP / WAIT Mode	27
9. Technical data.....	27
9.1. Memory requirements	27
10. Files shipped with embOS	28
11. Index	29

1. About this document

This guide describes how to use embOS Real Time Operating System for the STMicroelectronics ARM series of microcontrollers using *ARM RealView Developer Kit*.

1.1. How to use this manual

This manual describes all CPU and compiler specifics for embOS using ARM based controllers with *ARM RealView Developer Kit*. Before actually using *embOS*, you should read or at least glance through this manual in order to become familiar with the software.

Chapter 2 gives you a step-by-step introduction, how to install and use *embOS* using *ARM RealView Developer Kit*. If you have no experience using *embOS*, you should follow this introduction, because it is the easiest way to learn how to use *embOS* in your application.

Most of the other chapters in this document are intended to provide you with detailed information about functionality and fine-tuning of embOS for the ARM based controllers using *ARM RealView Developer Kit*.

2. Using *embOS* with ARM RealView Developer Kit

2.1. Installation

embOS is shipped on CD-ROM or as a zip-file in electronic form.

In order to install it, proceed as follows:

If you received a CD, copy the entire contents to your hard-drive into any folder of your choice. When copying, please keep all files in their respective sub directories. Make sure the files are not read only after copying.

If you received a zip-file, please extract it to any folder of your choice, preserving the directory structure of the zip-file.

Assuming that you are using *RealView Debugger* to develop your application, no further installation steps are required. You will find a prepared sample start application, which you should use and modify to write your application. So follow the instructions of the next chapter 'First steps'.

You should do this even if you do not intend to use the project manager for your application development in order to become familiar with *embOS*.

If for some reason you will not work with the project manager, you should: Copy either all or only the library-file that you need to your work-directory. This has the advantage that when you switch to an updated version of *embOS* later in a project, you do not affect older projects that use *embOS* also.


embOS does in no way rely on *ARM RealView Debugger* project manager, it may be used without the project manager using batch files or a make utility without any problem.

2.2. First steps


After installation of *embOS* (→ Installation) you are able to create your first multitasking application. You received several ready to go sample start projects and it is a good idea to use one of these as a starting point of all your applications.

To get your new application running, you should proceed as follows:

- Create a work directory for your application, for example c:\work
- Copy the whole folder 'Start' which is part of your *embOS* distribution into your work directory
- Clear the read only attribute of all files in the new 'start' folder.
- Create a new workspace file (**Menu** File\New\Workspace)
- For a better overview setup the right panel window to be a "Process Control" (**Menu** View\Pane Views\Process Control Pane)
- open the project file "Start_STR7xx.prj" for the STR7xx Starterkit with *ARM RealView Developer Kit* "RealView Debugger" (**Menu** Project\Open Project...)




- Now open a connection to your target (Menu: File\Connection\Connect To



- Build the start project

Your screen should look like follows:



For latest information you should open the file start\ReadMe.txt.

2.2.1. The sample application Main.c

The following is a printout of the sample application main.c. It is a good starting-point for your application. (Please note that the file actually shipped with your port of *embOS* may look slightly different from this one)

What happens is easy to see:

After initialization of *embOS*; two tasks are created and started

The 2 tasks are activated and execute until they run into the delay, then suspend for the specified time and continue execution.

```

/*****
*          SEGGER MICROCONTROLLER SYSTEME GmbH
*   Solutions for real time microcontroller applications
*****/
File      : Main.c
P urpose   : Skeleton program for embOS
-----  END-OF-HEADER  -----*/

#include "RTOS.h"
#include "LED.h"

OS_STACKPTR int Stack0[128], Stack1[128]; /* Task stacks */
OS_TASK TCB0, TCB1;                       /* Task-control-blocks */

void Task0(void) {
    while (1) {
        LED_ToggleLED0();
        OS_Delay (50);
    }
}

void Task1(void) {
    while (1) {
        LED_ToggleLED1();
        OS_Delay (200);
    }
}

/*****
*
*          main
*
*****/

int main(void) {
    OS_IncDI();           /* Initially disable interrupts */
    OS_InitKern();       /* initialize OS */
    OS_InitHW();         /* initialize Hardware for OS */
    LED_Init();          /* initialize LED ports */
    /* You need to create at least one task here ! */
    OS_CREATETASK(&TCB0, "HP Task", Task0, 100, Stack0);
    OS_CREATETASK(&TCB1, "LP Task", Task1, 50, Stack1);
    OS_Start();          /* Start multitasking */
    return 0;
}

```

2.3. Stepping through the sample application Main.c using the integrated debugger


To start the debugger click the checkbox “Load” in the Process Control Window to download the image to target. You will usually see the main function (very similar to the screenshot below). You may look at the startup code and have to set a breakpoint at main. Now you can step through the program.

OS_IncDI() initially disables interrupts.

OS_InitKern() is part of the *embOS* library; you can therefore only step into it in disassembly mode. It initializes the relevant OS-Variables. Because of the previous call of OS_IncDI(), interrupts are not enabled during execution of OS_InitKern().

OS_InitHW() is part of RTOSInit_*.c and therefore part of your application. Its primary purpose is to initialize the hardware required to generate the timer-tick-interrupt for *embOS*. Step through it to see what is done.

OS_Start() should be the last line in main, since it starts multitasking and does not return.



Before you step into `OS_Start()`, you should set two break points in the two tasks as shown below.

The screenshot displays the RVDEBUG debugger interface for the project `Start_STR71x` on an `ARM7TDMI_0:ARM-ARM-USB` target. The main window shows the source code of `main_led.c` with two break points (red dots) set in the `Task0` and `Task1` functions. The `Task0` function contains a loop that calls `LED_ToggleLEDO()` and `OS_Delay(50)`. The `Task1` function contains a loop that calls `LED_ToggleLED1()` and `OS_Delay(200)`. The `OS_Start()` function is also visible, showing the initialization of task stacks and task-control blocks.

The **Process Control** window on the right shows the loaded image `Start_STR71x.axf` and the project sources, including `LED.c`, `Main_LED.c`, `OS_Error.c`, `retarget.c`, `RTOSINIT_STR71x.c`, and `UserIRQ.c`. The **Call Stack** window shows the current call stack with `int main(void) Line #35` and `unknown __rt_entry(void)`. The **Locals** window shows the `OS_Time` variable with a value of `0`. The **Watch** window is empty. The **Memory** window shows the memory dump starting at `00000000` with values `0xE59FF018` and `0xE59FF018`. The **Output** window shows the memory statistics:


```

=====
Total RO Size (Code + RO Data)      7658 ( 7.48kB)
Total RW Size (RW Data + ZI Data)   1687 ( 1.65kB)
Total ROM Size (Code + RO Data + RW Data) 7658 ( 7.48kB)
=====

```

The **Current State of Processor** window at the bottom shows the current state of the processor, including the instruction pointer (Ln 35, Col 1) and the number of instructions (NUM).

As `OS_Start()` is part of the *embOS* library, you can step through it in disassembly mode only. You may press **GO**, step over `OS_Start()`, or step into `OS_Start()` in disassembly mode until you reach the highest priority task.



If you continue stepping, you will arrive in the task with lower priority:


The screenshot shows the RVDEBUG debugger interface for an ARM7TDMI target. The main window displays the source code for `main_led.c`. The code defines two tasks, `Task0` and `Task1`, each with a `while (1)` loop. `Task0` calls `LED_ToggleLED0()` and `OS_Delay(50)`. `Task1` calls `LED_ToggleLED1()` and `OS_Delay(200)`. The `LED_ToggleLED1()` function is highlighted in red, indicating it is the current execution point. The Process Control panel on the right shows the loaded image and project settings, including the project name `Start_STR71x` and the source files `LED.c`, `Main LED.c`, `OS_Error.c`, `retarget.c`, `RTOSINIT_STR71x.c`, `UserIRQ.c`, `heap.s`, and `ASSEMBLE=arm`. The Call Stack window shows the current function `void Task1(void) Line #24` and the previous function `void Task1(void) Line #22`. The Watch window shows the value of `OS_Time` as 2. The Memory window shows a dump of memory addresses from `00000000` to `00000038`. The Output window shows the memory usage summary:

Category	Size	Value
Total RO	Size (Code + RO Data)	7658 (7.48kB)
Total RW	Size (RW Data + ZI Data)	1687 (1.65kB)
Total ROM	Size (Code + RO Data + RW Data)	7658 (7.48kB)

The current state of the processor is shown as `Ln 35, Col 1` and `NUM`.

Continuing to step through the program, there is no other task ready for execution. *embOS* will therefore start the idle-loop, which is an endless loop which is always executed if there is nothing else to do (no task is ready, no interrupt routine or timer executing).

You will arrive there when you step into the `OS_Delay()` function in disassembly mode. `OS_Idle()` is part of `RTOSInit*.c`. You may also set a breakpoint there before you step over the delay in `Task1`.



If you set a breakpoint in one or both of our tasks, you will see that they continue execution after the given delay.

As can be seen by the value of **embOS** timer variable OS_Time, shown in the watch window, Task0 continues operation after expiration of the 50 ms delay.

The screenshot displays the RVDEBUG debugger interface for an ARM7TDMI target. The main window shows the source code for `main_led.c`. The `OS_Delay (50);` line in the `Task0` function is highlighted, indicating the current execution point. The `OS_Time` variable is shown in the Watch window with a value of 52. The Process Control window shows the loaded image and project settings. The Call Stack window shows the current function call. The Output window shows several "Command pending" messages.

```

void Task0(void) {
    while (1) {
        LED_ToggleLEDO();
        OS_Delay (50);
    }
}

void Task1(void) {
    while (1) {
        LED_ToggleLED1();
        OS_Delay (200);
    }
}

/*****
 *
 *      main
 *
 *****/
    
```

Name	Value
void Task0(void) Line #18	
void Task0(void) Line #15	

Name	Value
OS_Time	52

Type	Value
ARM7TDMI	PC=0x200005E0
Image	Start_STR71x.axf
Load	Image+Symbols
Project	Start_STR71x
Settin...	<Saved>
Sources	From Project
COMPILE=arm	
LED.c	
Main_LED.c	
OS_Error.c	
reTarget.c	
RTOSINIT_STR71x.c	
UserIRQ.c	
COMPILE=arm_cpp	
COMPILE=thumb	
ASSEMBLE=arm	
heap.s	

Address	Value
00000000	0xE59FF018 0xE59FF018
00000008	0xE59FF018 0xE59FF018
00000010	0xE59FF018 0xE1A00000
00000018	0xE59FF014 0xE59FF014
00000020	0x20001AE0 0x2000003C
00000028	0x20000040 0x20000044
00000030	0x20000048 0x20001928
00000038	0x2000004C 0xF4FFFFFF

Command pending until execution stops. Use 'Cancel' to purge.

Command pending until execution stops. Use 'Cancel' to purge.

Command pending until execution stops. Use 'Cancel' to purge.

Command pending until execution stops. Use 'Cancel' to purge.

Command pending until execution stops. Use 'Cancel' to purge.

Command pending until execution stops. Use 'Cancel' to purge.

Command pending until execution stops. Use 'Cancel' to purge.

Command pending until execution stops. Use 'Cancel' to purge.

Ln 18, Col 1

3. Build your own application

To build your own application, you should always start with a copy of the sample start workspace and project. Therefore copy the entire folder “Start” from your *embOS* distribution into a working folder of your choice and then modify the start project there. This has the advantage, that all necessary files are included and all settings for the project are already done.

3.1. Required files for an *embOS* application

To build an application using *embOS*, the following files from your *embOS* distribution are required and have to be included in your project:

- **RTOS.h** from sub folder Inc\
This header file declares all *embOS* API functions and data types and has to be included in any source file using *embOS* functions.
- **RTOSInit_*.c** from one CPU subfolder.
It contains hardware dependent initialization code for *embOS* timer and optional UART for embOSView.
- **init_*.s** from one of the CPU subfolder.
It contains the low level initialization of the hardware and setup of the various stack pointer.
- **scat_*.scf** from one of the CPU subfolder.
It contains the linker settings.
- One ***embOS* library** from the Lib\ subfolder
- **RTOSVect.s** from the Src\ subfolder.
It contains the low level interrupt handler entry for ARM CPUs running with *embOS*.
- **OS_Error.c** from subfolder Src\
The error handler is used if any library other than Release build library is used in your project.
- **vector.s** from the Src\ subfolder.
This file contains the ARM vector table
- **retarget.c** from the Src\ subfolder.
Since you use your own linker file (scatter file) some functions need to be rewritten for the ARM RealView Developer Kit’s runtime library. The delivered retarget.c file is already prepared for usage with *embOS*. If you want to modify this file, please refer to the *ARM Compilers and Libraries Guide*
- Additional low level init code may be required according to CPU.

When you decide to write your own startup code, please use one of the init_*.s as template. Also ensure, that main is called with CPU running in supervisor or system mode.

Your main() function has to initialize *embOS* by call of OS_InitKern() and OS_InitHW() prior any other *embOS* functions are called.

You should then modify or replace the main.c source file in the subfolder src\.

3.2. Change library mode

For your application you may wish to choose an other library. For debugging and program development you should use an *embOS* -debug library. For your final application you may wish to use an *embOS* -release library or a stack check library.

Therefore you have to select or replace the *embOS* library in your project or target:

- Replace the Linker options (Menu Project\Project Settings *BUILD) and replace the OS*.a string with the desired library.
- Check and set the appropriate OS_LIBMODE_* define as preprocessor option. (Menu Project\Project Settings *Compile_arm*\Preprocessor)

4. ARM specifics

4.1. CPU modes

embOS supports nearly all memory and code model combinations that ARM RealView Developer Kit's C-Compiler supports.

embOS was compiled with interwork options. Therefore it is required to compile the projects with interwork option too.

4.2. Available libraries

embOS for ARM for ARM RealView Developer Kit is shipped with 6 different libraries, one for each library type.

The libraries are named as follows:

OS<Mode>4L<LibMode>.a

Parameter	Meaning	Values
Mode	Specifies the CPU mode	A: ARM mode T: THUMB mode
4	Specifies the CPU variant	4: core type4: ARM 7/9
L	Endian mode	L: Little
LibMode	Library mode	R: Release S: Stack check D: Debug SP: Stack check + profiling DP: Debug + profiling DT: Debug + trace

Example:

ost4LR.a the library for a project using THUMB mode, ARM 7/9 core, little endian mode and release build library type.

5. Stacks

5.1. Task stack for ARM 7 and ARM 9

All *embOS* tasks execute in *system mode*. The stack-size required is the sum of the stack-size of all routines plus basic stack size.

The basic stack size is the size of memory required to store the registers of the CPU plus the stack size required by *embOS* -routines.

For the ARM 7/9, this minimum task stack size is about 68 bytes.

5.2. System stack for ARM 7 and ARM 9

The *embOS* system executes in *supervisor mode*. The minimum system stack size required by *embOS* is about 136 bytes (stack check & profiling build). However, since the system stack is also used by the application before the start of multitasking (the call to `OS_Start()`), and because software-timers and "C"-level interrupt handlers also use the system-stack, the actual stack requirements depend on the application.

The size of the system stack can be changed by modifying value of `Len_SVC_Stack` in the file `init_*.s`.

5.3. Interrupt stack for ARM 7 and ARM 9

If a normal hardware exception occurs, the ARM core switches to *IRQ mode*, which has a separate stack pointer. To enable support for nested interrupts, execution of the ISR itself in a different CPU mode than *IRQ mode* is necessary. *embOS* switches to *supervisor mode* after saving scratch registers, `LR_irq` and `SPSR_irq` onto the *IRQ stack*.

As a result, only registers mentioned above are saved on the *IRQ stack*. For the interrupt routine itself, the supervisor stack is used.

The size of the interrupt stack can be changed by modifying value of `Len_IRQ_Stack` in the file `init_*.s`. We recommend at least 128 bytes.

5.4. Stack specifics of the ARM family

Exceptions require space on the supervisor and interrupt stack. The interrupt stack is used to store contents of scratch registers, the ISR itself uses supervisor stack.

6. Heap

6.1. Heap management

If you intend to use heap for dynamic memory allocation, the scatter file (scat_*.scf) needs to be modified. Per default a heap of 4 kBytes are reserved:

Example

```

;*****
; *          SEGGER MICROCONTROLLER SYSTEME GmbH          *
; * Solutions for real time microcontroller applications *
;*****
; *          (C) 2002-2005 SEGGER Microcontroller Systeme GmbH *
; *          www.segger.com          Support: support@segger.com *
;*****
;
;-----
;File      : scat_STR71x_ROM.scf
;Purpose   : Scatter file for use with ST STR71x to run with
;           : internal ROM/RAM
;-----END-OF-HEADER-----
;
;
; This scatterloading descriptor file defines:
; one load region (STR71x) and a number of execution regions
; (FLASH & XRAM etc.)
;
; The region HEAP is used to locate the bottom of the heap
; The heap will grow up from this address
;
; The region STACKS is used to locate the top of the memory used to store
; the stacks for each mode. The stacks will grow down from this address
;

FLASH 0x40000000 0x01000000
{
;      Addr.      Flags      Len
;      FLASH 0x40000000      0x1FFFF
;      {
;          vectors.o (Vect, +First)
;          init*.o (Init)
;          * (+RO)
;      }
;      Addr.      Flags      Len
;      XRAM 0x20000000      0x2D00
;      {
;          * (+RW,+ZI)
;      }
;      Addr.      Flags      Len
;      STACK +0x0000      EMPTY      0x0300
;      {
;      }
;      Addr.      Flags      Len
;      HEAP  +0x0      EMPTY      0x1000
;      {
;      }
}

```

7. Interrupts

7.1. What happens when an interrupt occurs?

- The CPU-core receives an interrupt request
- As soon as the interrupts are enabled, the interrupt is executed
- the CPU switches to the Interrupt stack
- the CPU saves PC and flags in registers LR_irq and SPSR_irq
- the CPU jumps to the vector address 0x18
- **embOS** OS_IRQ_SERVICE: save scratch registers
- **embOS** OS_IRQ_SERVICE: save LR_irq and SPSR_irq
- **embOS** OS_IRQ_SERVICE: switch to *supervisor mode*
- **embOS** OS_IRQ_SERVICE: execute OS_irq_handler (defined in RTOSINIT*.C)
- **embOS** OS_irq_handler: check for interrupt source and execute timer interrupt, serial communication or user ISR.
- **embOS** OS_IRQ_SERVICE: switch to *IRQ mode*
- **embOS** OS_IRQ_SERVICE: restore LR_irq and SPSR_irq
- **embOS** OS_IRQ_SERVICE: pop scratch registers
- return from interrupt

When using an ARM derivate with vectored interrupt controller, please ensure that OS_IRQ_SERVICE is called from every interrupt. The interrupt vector itself may then be examined by the "C"-level interrupt handler in RTOSInit*.c.

7.2. Defining interrupt handlers in "C"

Interrupt handlers called from **embOS** interrupt handler in RTOSInit*.c are just normal "C"-functions which do not take parameters and do not return any value.

The default C interrupt handler OS_irq_handler() in RTOSInit*.c first calls OS_EnterInterrupt() or OS_EnterNestableInterrupt() to inform **embOS** that interrupt code is running. Then this handler examines the source of interrupt and calls the related interrupt handler function.

Finally the default interrupt handler OS_irq_handler() in RTOSInit*.c calls OS_LeaveInterrupt() or OS_LeaveNestableInterrupt() and returns to the primary interrupt handler OS_IRQ_SERVICE().

Depending on the interrupting source, it may be required to reset the interrupt pending condition of the related peripherals.

Example

"Simple" interrupt-routine

```
void Timer_irq_func(void) {
    if (__INTPND & 0x0800) { // Interrupt pending ?
        __INTPND = 0x0800; // reset pending condition
        OSTEST_X_ISR0(); // handle interrupt
    }
}
```

7.3. Interrupt handling with vectored interrupt controller

For ARM derivatives with built in vectored interrupt controller, *embOS* uses a different interrupt handling procedure and delivers additional functions to install and setup interrupt handler functions.

When using an ARM derivative with vectored interrupt controller, please ensure that `OS_IRQ_SERVICE()` is called from every interrupt. This is default when startup code and hardware initialization delivered with *embOS* is used.

The interrupt vector itself will then be examined by the “C”-level interrupt handler `OS_irq_handler()` in `RTOSInit*.c`.

You should not program the interrupt controller for IRQ handling directly. You should use the functions delivered with *embOS*.

The reaction to an interrupt with vectored interrupt controller is as follows:

- *embOS* `OS_IRQ_SERVICE()` is called by CPU or interrupt controller.
- `OS_IRQ_SERVICE()` saves registers and switches to supervisor mode.
- `OS_IRQ_SERVICE()` calls `OS_irq_handler()` (in `RTOSInit*.c`).
- `OS_irq_handler()` examines the interrupting source by reading the interrupt vector from the interrupt controller.
- `OS_irq_handler()` informs *embOS* that interrupt code is running by a call of `OS_EnterNestableInterrupt()` which re-enables interrupts.
- `OS_irq_handler()` calls the interrupt handler function which is addressed by the interrupt vector.
- `OS_irq_handler()` resets the interrupt controller to re-enable acceptance of new interrupts.
- `OS_irq_handler()` calls `OS_LeaveNestableInterrupt()` which disables interrupts and informs *embOS* that interrupt handling finished.
- `OS_irq_handler()` returns to `OS_IRQ_SERVICE()`.
- `OS_IRQ_SERVICE()` restores registers and performs a return from interrupt.

Please note, that different ARM CPUs may have different versions of vectored interrupt controller hardware and usage of *embOS* supplied functions varies depending on the type of interrupt controller. Please refer to the samples delivered with *embOS* which are used in the CPU specific `RTOSInit` module.

To handle interrupts with vectored interrupt controller, *embOS* offers the following functions:

7.3.1. OS_ARM_InstallISRHandler(): Install an interrupt handler

Description

OS_ARM_InstallISRHandler() is used to install a specific interrupt vector when ARM CPUs with vectored interrupt controller are used.

Prototype

```
OS_ISR_HANDLER* OS_ARM_InstallISRHandler (int ISRIndex,  
                                           OS_ISR_HANDLER* pISRHandler);
```

Parameter	Meaning
ISRIndex	Index of the interrupt source, normally the interrupt vector number.
pISRHandler	Address of the interrupt handler function.

Return value

OS_ISR_HANDLER*: the address of the previous installed interrupt function, which was installed at the addressed vector number before.

Add. information

This function just installs the interrupt vector but does not modify the priority and does not automatically enable the interrupt.

7.3.2. OS_ARM_EnableISR(): Enable specific interrupt

Description

OS_ARM_EnableISR() is used to enable interrupt acceptance of a specific interrupt source in a vectored interrupt controller.

Prototype

```
void OS_ARM_EnableISR(int ISRIndex)
```

Parameter	Meaning
ISRIndex	Index of the interrupt source which should be enabled.

Return value

NONE.

Add. information

This function just enables the interrupt inside the interrupt controller. It does not enable the interrupt of any peripherals. This has to be done elsewhere.

For ARM CPUs with VIC type interrupt controller, this function just enables the interrupt vector itself. To enable the hardware assigned to that vector, you have to call OS_ARM_EnableISRSource() also.

7.3.3. OS_ARM_DisableISR(): Disable specific interrupt

Description

OS_ARM_DisableISR() is used to disable interrupt acceptance of a specific interrupt source in a vectored interrupt controller which is not of the VIC type.

Prototype

```
void OS_ARM_DisableISR(int ISRIndex);
```

Parameter	Meaning
ISRIndex	Index of the interrupt source which should be disabled.

Return value

NONE.

Add. information

This function just disables the interrupt controller. It does not disable the interrupt of any peripherals. This has to be done elsewhere.

When using an ARM CPU with built in interrupt controller of VIC type, please use OS_ARM_DisableISRSource() to disable a specific interrupt.

7.3.4. OS_ARM_ISRSetPrio(): Set priority of specific interrupt

Description

OS_ARM_ISRSetPrio () is used to set or modify the priority of a specific interrupt source by programming the interrupt controller.

Prototype

```
int OS_ARM_ISRSetPrio(int ISRIndex, int Prio);
```

Parameter	Meaning
ISRIndex	Index of the interrupt source which should be modified.
Prio	The priority which should be set for the specific interrupt.

Return value

Previous priority which was assigned before the call of OS_ARM_ISRSetPrio().

Add. information

This function sets the priority of an interrupt channel by programming the interrupt controller. Please refer to CPU specific manuals about allowed priority levels.

This function can not be used to modify the interrupt priority for interrupt controllers of the VIC type. The interrupt priority with VIC type controllers depends on the interrupt vector number and can not be changed.

7.4. Interrupt-stack switching

Since ARM core based controllers have a separate stack pointer for interrupts, there is no need for explicit stack-switching in an interrupt routine. The routines `OS_EnterIntStack()` and `OS_LeaveIntStack()` are supplied for source compatibility to other processors only and have no functionality.

The ARM interrupt stack is used for primary interrupt handler in `RTOSVect.s` only.

7.5. Fast Interrupt FIQ

FIQ interrupt can not be used with *embOS* functions, it is reserved for high speed user functions.

FIQ is never disabled by *embOS*.

Never call any *embOS* function from an FIQ handler.

Do not assign any *embOS* interrupt handler to FIQ.

When you decide to use FIQ, please ensure that FIQ stack is initialized during startup and an interrupt vector for FIQ handling is included in your application.

8. STOP / WAIT Mode

In case your controller does support some kind of power saving mode, it should be possible to use it also with *embOS*, as long as the timer keeps working and timer interrupts are processed. To enter that mode, you usually have to implement some special sequence in function `OS_Idle()`, which you can find in *embOS* module `RTOSINIT.c`.

9. Technical data

9.1. Memory requirements

These values are neither precise nor guaranteed but they give you a good idea of the memory-requirements. They vary depending on the current version of *embOS*. Using ARM mode, the minimum ROM requirement for the kernel itself is about 2.500 bytes. In THUMB mode kernel itself does have a minimum ROM size of about 1.700 bytes.

In the table below, you can find minimum RAM size for *embOS* resources. Please note, that sizes depend on selected *embOS* library mode; table below is for a release build.

<i>embOS</i> resource	RAM [bytes]
Task control block	32
Resource semaphore	16
Counting semaphore	8
Mailbox	20
Software timer	20

10. Files shipped with *embOS*

Directory	File	Explanation
root	*.pdf	Generic API and target specific documentation.
root	Release.html	Version control document.
root	embOSView.exe	Utility for runtime analysis, described in generic documentation.
START	Start*.prj	Sample project files for ARM RealView Debugger IDE.
START\INC	RTOS.H	Include file for <i>embOS</i> , to be included in every "C"-file using <i>embOS</i> –functions.
START\LIB	os*.a	<i>embOS</i> libraries
START\SRC	main.c	Sample frame program to serve as a start.
START\SRC	OS_Error.c	<i>embOS</i> runtime error handler used in stack check or debug builds.
START\SRC	retarget.c	ARM runtime library initialization
START\SRC	RTOSVect.s	<i>embOS</i> interrupt handler
START\SRC	Vector.s	ARM vector table.
START\CPU_*	*.*	CPU specific hardware routines for various CPUs.

Any additional file shipped as example.

11. Index

F

First steps 6

H

Halt-mode 27

Heap 19

I

Idle-task-mode 27

Installation 5

Interrupt stack 18, 26

Interrupts 20

Interrupts, FIQ 26

L

Len_SVC_Stack 18

Libraries

available 17

change 16

M

Memory models 17

memory requirements 27

O

OS_ARM_DisableISR() 24

OS_ARM_EnableISR() 23

OS_ARM_InstallISRHandler() 22

OS_ARM_ISRSetPrio() 25

OS_irq_handler() 20

OS_IRQ_SERVICE() 20

R

Required files 15

S

Sample

main() 8

Stacks 18

Stacks, interrupt stack 18

Stacks, system stack 18

Stop-mode 27

System stack 18

T

target hardware 27

W

Wait-mode 27